


No less than 6" from outside edge to avoid internal corner gusset.

Remaining screws are patterned on all 4 four side as follows:

- No more than 24" apart for Screen Wall Panels and Walls utilizing inserts.
- No more than 36" apart for Screen Wall Panels and Walls not utilizing inserts.

Screw pattern is the same for side screwing and face screwing

	
CONNECTICUT SCREEN WORKS, INC Wallingford, CT 06492 (203) 741-0895	
Title: Face Screwing / Side Screwing	
Date: 12/01/2011	By: MC
Scale: N/A	Rev:
Page: 1 OF 1	Rev:
Alloy: N/A	Rev:
Temper: N/A	Patent: 7,938,163
Length: N/A	<i>Others Pending</i>
Die:	
<small>all contents copyright 2006 by CSW, Inc.</small>	